Agricultural Disease Management: Estimation of Cercospora Leaf Spot Severity in Table Beets using UAS



Mohammad S Saif, Robert Chancia, Pratibha Sharma, Sean P. Murphy, Sarah Pethybridge and Jan van Aardt



Background

- Cercospora leaf spot (CLS) is a foliar fugal disease common in beet plants.
- CLS causes reddish brown spots of size 2-5 mm on foliage.
- Spots spread and grow, eventually leading to defoliation.
- Early onset leading to significant yield losses.
- Associated defoliation poses a challenge for mechanical harvesters.









Disease Severity

DIRS

- Disease severity (DS) is a metric that is used to quantify CLS in table beets, i.e., the percentage of leaf area covered by the lesions.
- Several leaves are sampled and visually scored to assess an entire plot.
- The same observer must score DS each season to ensure consistency.



Objective



Assess *Cercospora* leaf spot (CLS) disease severity in table beets using unmanned aerial systems (UAS).



Data Collection

DIRS

- Study area: Geneva, New York, USA, at Cornell AgriTech.
- 2021 & 2022 flights: DJI
 Matrice-600 with a MicaSense
 RedEdge-M camera capturing
 five-band multispectral images
 (475, 560, 668, 717, & 840 nm).
- 2023 Flight: DJI Mavic 3M was used to capture fourband multispectral images (560, 650, 730, & 860 nm)
- **Dimension of plot:** 10ft x 2, each plot demarcated by flags








Timeline for Data Collection




- Five flight campaigns were performed each season, resulting a total of 15 flights across three seasons.
- For 2021 and 2022 there were 40 plots each year.
- For 2023 there were 56 plots.
- Total data points = 40x5 + 40x5 + 56x5 = 680





Note: Data Alignment

- Visual disease assessment did not always align with flight date.
- We thus used a 2nd order linear interpolation to approximate the disease severity on the day of the flight.










Processing Flow Chart

- MSAVI2 > 0.25 is used to extract beet vegetation canopy.
- Reflectance maps consists of 4 bands (green, red, red-edge, NIR).
- 6 descriptive statistics are extracted from each maps for each bands.





Vegetation Indices



- VI a placeholder for vegetation health
- VIs chosen based on past studies

Abbreviation	Name	Formula	Ref	
RDVI	Renormalized Difference Vegetation Index	$\frac{R_{NIR} - R_{Red}}{\sqrt{R_{NIR} + R_{Red}}}$	Steddom et al., (2005)	
NGRDVI	Normalized Green-Red difference vegetation index	$\frac{R_{Green} - R_{Red}}{R_{Green} + R_{Red}}$	Jay et al. (2020)	
HI	Health Index	$\frac{R_{534} - R_{698}}{R_{534} + R_{698}} - 0.5R_{704}$	Mahlein et al. (2013)	
CLSI	Cercospora Leaf Spot Index	$\frac{R_{698} - R_{570}}{R_{698} + R_{570}} - R_{734}$		
MCARI2	MCARI (variant with reduced soil contamination)	$\frac{1.5[2.5(R_{800} - R_{670}) - 1.3(R_{800} - R_{550})]}{\sqrt{(2R_{800} + 1)^2 - (6R_{800} - 5\sqrt{R_{670}}) - 0.5}}$	Barreto et al. (2023)	
MSAVI2	Modified Soil-adjusted Vegetation Index (variant)	$\frac{2R_{NIR} + 1 - \sqrt{(2R_{NIR} + 1)^2 - 8(R_{NIR} - R_{Red})}}{2}$		
GVI	Green Vegetation Index	$-0.283R_{Green} - 0.660R_{Red} + 0.577R_{RedEdge} + 0.388R_{NIR}$		
MCARIOSAVI	Modified chlorophyll absorption ratio/ Optized soil adjusted vegetation indices	$\frac{[(R_{700} - R_{670}) - 0.2(R_{700} - R_{550})](R_{840} + R_{670} + 0.16)}{1.16(R_{840} - R_{670})(R_{700}/R_{670})}$		

Texture Features

- Proxy for a pixel-spatial relationship.
- Spatial variation of pixels could provide information about the frequency of CLS presence in a plot.
- Find gray level co-occurrence Matrix (GLCM) (Haralick et al., 1973).
- Extract each texture feature using descriptive statistics of GLCM.
- A single four band image generates 4x8 = 32 feature maps

		222	DIRS
No.	Texture Features	Formula	1
1	Mean (mean)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} i * P(i,j)$	
2	Variance (var)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} (i - ME)^{2*} P(i,j)$	
3	Contrast (cont)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} (i-j)^2 * P(i,j)$	
4	Dissimilarity (dis)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} i - j * P(i, j)$	
5	Homogenity (homo)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} i * \frac{P(i,j)}{1 + (i-j)^2}$	
6	Entropy (ent)	$-\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} P(i,j) * \ln P(i,j)$	
7	Angular Second Moment (asm)	$\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} P(i,j)^2$	
		$\frac{\sum_{i=1}^{N_g} \sum_{j=1}^{N_g} ij P(i,j) - \mu_x \mu_y}{\sigma_x \sigma_y}$	
8	Correlation	Where μ_x , μ_y , σ_x and σ_y are the means and standard deviations of p_x and p_y	
		$p_x(i) = \sum_{j=1}^{N_g} P(i,j)$ and $p_y(j) = \sum_{i=1}^{N_g} P(i,j)$	11


Feature Extraction



- Calculate mean, coefficient of variation, first quartile, third quartile, skewness and kurtosis from each feature maps.
- Total number of features:
 - 8 VIs x 6 statistics + 4 bands x 6 statistics + 4 bands x 8 texture
 features x 6 statistics = 264

Model Development





Best-performing Results





Random forest model exhibited the best result with the least number of features.

Models	Hyperparameters	No. of features	Features used	R ² _{train} / RMSE	R ² _{val} / RMSE _{val} (%)	R ² test / RMSE test
RF	n_estimators: 100, max_depth: 8, min_samples_split: 3, min_samples_leaf: 2	2	rdvi_skewness, tex_homo_cv_4	0.89 / 6.92	0.87 / 8.09	0.82 / 9.31
XGB	n_estimators: 50, learning_rate: 0.1, max_depth: 3	7	rdvi_skewness, ref_q3_3, tex_cont_cv_2, tex_cont_q3_4, tex_homo_cv_4, tex_homo_kurtosis_4, tex_mean_q3_1	0.93 / 5.82	0.89 / 7.61	0.81 / 9.65
SVR	kernel: rbf, C: 1, epsilon: 0.001	8	gvi_kurtosis, ref_skewness_3, ref_skewness_4, tex_cont_q1_4, tex_homo_cv_3, tex_homo_skewness_4, tex_mean_cv_4, tex_var_kurtosis_4	0.88 / 7.50	0.81 / 9.90	0.78 / 10.27
PLSR	n_components: 5	5	gvi_kurtosis, ref_skewness_3, ref_skewness_4, tex_homo_cv_3, tex_mean_mean_4	0.76 / 10.33	0.83 / 9.36	0.79 / 10.17

Model Performance and Feature Analysis








CLS Maps: Examples of Field-level CLS





Conclusions



- Our work demonstrates the feasibility of utilizing multiple UAS systems for estimating CLS disease severity.
- We achieved comparable accuracy to contemporary literature at a relatively low resolution (~1 cm).
- RDVI skewness (red and NIR band) and texture homogeneity coefficient of variation of NIR band are important indices for determining CLS.



Questions?



Acknowledgements: Timothy Bauch, Nina Raqueno

Funding: This research principally was supported by Love Beets USA and the New York Farm Viability Institute (NYFVI), as well as the United States Department of Agriculture (USDA), National Institute of Food and Agriculture Health project NYG-625424, managed by Cornell AgriTech at the New York State Agricultural Experiment Station (NYSAES), Cornell University, Geneva, New York.